TTK 33 E










Table of contents

Notes regarding the instructions	2
Safety	2
Information about the device	5
Transport and storage	6
Assembly and start-up	7
Operation	8
Errors and faults	11
Available accessories	12
Maintenance	13
Technical annex	16
Disposal	19

Notes regarding the instructions

Symbols



Danger

This symbol indicates dangers to the life and health of persons due to extremely flammable gas.



Warning of electrical voltage

This symbol indicates dangers to the life and health of persons due to electrical voltage.



Warning

This signal word indicates a hazard with an average risk level which, if not avoided, can result in serious injury or death.



Caution

This signal word indicates a hazard with a low risk level which, if not avoided, can result in minor or moderate injury.

Note

This signal word indicates important information (e.g. material damage), but does not indicate hazards.



Info

Information marked with this symbol helps you to carry out your tasks quickly and safely.



Follow the manual

Information marked with this symbol indicates that the instructions must be observed.

You can download the current version of the instructions and the EU declaration of conformity via the following link:



TTK 33 E



https://hub.trotec.com/?id=45052

Safety

Read this manual carefully before starting or using the device. Always store the manual in the immediate vicinity of the device or its site of use.



Warning

Read all safety warnings and all instructions.

Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury. Save all warnings and instructions for future reference.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children

- Do not use the device in potentially explosive rooms or areas and do not install it there.
- Do not use the device in aggressive atmosphere.

without supervision.

- Only put up the device in an upright, stable position on firm ground.
- Let the device dry out after a wet clean. Do not operate it when wet.
- Do not use the device with wet or damp hands.
- Do not expose the device to directly squirting water.
- Do not cover the device during operation.
- Do not sit on the device.
- This appliance is not a toy. Keep away from children and animals.
- Occasionally observe the device during operation.
- Check accessories and connection parts for possible damage prior to every use of the device. Do not use any defective devices or device parts.



- Ensure that all electric cables outside of the device are protected from damage (e.g. caused by animals). Never use the device if electric cables or the power connection are damaged!
- The mains connection must correspond to the specifications in the Technical annex.
- Insert the mains plug into a properly fused mains socket.
- Observe the device's power input, cable length and intended use when selecting extensions to the power cable. Completely unroll extension cables. Avoid electrical overload.
- Do not under any circumstances use the device if you detect damages on the mains plug or power cable. If the power cable is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. Defective power cables pose a serious health risk!
- Before carrying out maintenance, care or repair work on the device, remove the mains plug from the mains socket. Hold onto the mains plug while doing so.
- Switch the device off and disconnect the power cable from the mains socket when the device is not in use.
- When positioning the device, observe the minimum distances from walls and other objects as well as the storage and operating conditions specified in the Technical annex.
- Make sure that the air inlet and outlet are not obstructed.
- Make sure that the suction side is kept free of dirt and loose objects.
- Never insert any objects or limbs into the device.
- Do not remove any safety signs, stickers or labels from the device. Keep all safety signs, stickers and labels in legible condition.
- Only transport the device in an upright position with an emptied condensation tank or drain hose.
- Discharge the collected condensate before transport and storage. Do not drink it. Health hazard!
- Only use original spare parts, for otherwise safe and functional operation cannot be ensured.

Safety warnings for devices containing flammable refrigerants

- Only position the device in rooms where potentially leaking refrigerant cannot accumulate. Unventilated rooms, in which the device is installed, operated or stored, must be built in a way to ensure that potentially leaking refrigerant cannot accumulate. This serves to avoid fire or explosion hazards resulting from an ignition of the refrigerant by an electric furnace, cooking stove or another ignition source.
- Only position the device in rooms where there is no source of ignition (e.g. open flames, an active gas appliance or an electric heater).
- Please note that the refrigerant is odourless.
- Only install the device in compliance with the national installation regulations.
- Please observe the local regulations.
- Observe the national gas regulations.
- Only install, operate and store the device in a room measuring more than 4 m².
- Store the device in a way that no mechanical damage can occur.
- Please note that the connected pipelines must not contain any sources of ignition.
- R290 is a refrigerant that complies with European environmental regulations. No part of the cooling circuit may be perforated.
- Observe the maximum refrigerant capacity in the technical
- Do not drill through or burn.
- Do not use any means other than those recommended by the manufacturer for accelerating the defrosting process.
- Every person working with or at the refrigerant circuit must be able to provide a certificate of qualification issued by a body accredited by the industry, demonstrating their competence in the safe use of refrigerants based on a procedure well-known in the industry.
- Service work may only be carried out in accordance with the manufacturer's specifications. If maintenance and repair work require the support of additional persons, the person trained in handling flammable refrigerants shall continuously supervise the work carried out.
- The entire refrigerant circuit is a maintenance-free, hermetically sealed system and may only be maintained or repaired by specialist companies for cooling and airconditioning or by Trotec.
- Allow the device to cool down before transport and/or maintenance work.



Intended use

Only use the device for drying and dehumidifying room air, while adhering to and following the technical data.

In addition, the device may also be used as a kind of clothes dryer to dry wet laundry.

Intended use comprises:

- dehumidifying and drying:
 - living rooms, bedrooms, bathrooms and basements
 - laundries, holiday homes, camper vans, boats
- maintaining the dryness of:
 - storage spaces, archives, laboratories, garages
 - bathrooms, wash rooms, changing rooms etc.

Any use other than the intended use is regarded as misuse.

Reasonably foreseeable misuse

- The device is not intended for industrial use.
- Do not place the device on wet or flooded ground.
- Do not place any objects, e.g. clothing, on the device.
- Do not use the device out of doors.
- Do not use this device in immediate vicinity of swimming pools and showers.
- Never immerse the device in water.
- Do not make any unauthorised modifications, alterations or structural changes to the device.

Personnel qualifications

People who use this device must:

- be aware of the dangers that occur when working with electric devices in damp areas.
- have read and understood the instructions, especially the Safety chapter.

Maintenance tasks which require the housing to be opened must only be carried out by specialist companies for cooling and air-conditioning or by Trotec.

Safety signs and labels on the device

Note

Do not remove any safety signs, stickers or labels from the device. Keep all safety signs, stickers and labels in legible condition. The following safety signs and labels are attached to the device:

WARNING • WARNUNG • ATTENTION

DE Das Gerät muss in einem Raum mit einer Grundfläche größer als 4 m² aufgestellt, betrieben und gelagert werden.

EN Appliance shall be installed, operated and stored in a room with floor area larger than 4 m².

FR L'appareil doit être installé, utilisé et entreposé dans une pièce avec une surface supérieure à 4 m².





$\widetilde{\mathbf{i}}$

Follow the manual

This symbol indicates that the instructions must be observed.



Follow the repair manual

Disposal, maintenance and repair work of the refrigerant circuit may only be carried out in accordance with the manufacturer's specifications and by persons having a certificate of qualification. A corresponding repair manual is available from the manufacturer upon request.

Residual risks



Danger

Natural refrigerant propane (R290)!

H220 - Extremely flammable gas.

H280 – Contains gas under pressure; may explode if heated.

P210 – Keep away from heat, sparks, open flames and other ignition sources. No smoking.

P377 – Leaking gas fire: Do not extinguish, unless leak can be stopped safely.

P410+P403 – Protect from sunlight. Store in a well-ventilated place.



Warning of electrical voltage

Work on the electrical components must only be carried out by an authorised specialist company!



Warning of electrical voltage

Risk of electric shock!

Risk of an electric shock if the device comes into contact with water in showers or swimming pools!

Do not use this device in immediate vicinity to showers or swimming pools!

Never immerse the device in water!



Warning of electrical voltage

Before any work on the device, remove the mains plug from the mains socket!

Do not touch the mains plug with wet or damp hands. Hold onto the mains plug while pulling the power cable out of the mains socket.





Warning

Dangers can occur at the device when it is used by untrained people in an unprofessional or improper way! Observe the personnel qualifications!



Warning

The device is not a toy and does not belong in the hands of children.



Warning

Risk of suffocation!

Do not leave the packaging lying around. Children may use it as a dangerous toy.

Note

Do not operate the device without an air filter inserted into the air inlet!

Without the air filter, the inside of the device will be heavily contaminated. This could reduce the performance and result in damage to the device.

Behaviour in the event of an emergency

- 1. Switch the device off.
- Disconnect the device from the mains feed-in: Hold onto the mains plug while pulling the power cable out of the mains socket.
- 3. Do not reconnect a defective device to the mains.

Information about the device

Device description

The device uses the principle of condensation to automatically dehumidify rooms.

The fan sucks damp room air through the air inlet, the air filter, the evaporator and to the condenser located behind it. The air is cooled at the cold evaporator until it is below the dew point. Water vapour contained in the room air precipitates on the evaporator fins as condensation or rime. The dehumidified, cooled air is slightly warmed at the condenser and blown out again. The drier air thus conditioned mixes with the air in the room. The humidity in the room where the device is positioned is reduced as air constantly circulates through the device.

Depending on the air temperature and the relative humidity, the condensed water either drops continuously or only during the defrost phase through the integrated drain nozzle into the condensation tank below. It is fitted with a float to measure the filling level.

The device has a control panel for operating and controlling the functions.

Once the maximum filling level of the condensation tank is reached or in case the condensation tank is not installed correctly, the condensation tank indicator light (see chapter Operation) on the control panel is illuminated. The device switches off. The condensation tank indicator light only goes out again once the emptied condensation tank is reinserted.

Optionally, the condensed water can be drained by attaching a hose at the condensation connection.


In addition, the device may also be used as a kind of clothes dryer to dry wet laundry in living or working spaces.


Another feature is the device's self-cleaning function. This function serves to dry the interior of the device in order to prevent the formation of mould or similar inside the device due to residual moisture.


Because of the heat radiation generated during operation, the room temperature may rise slightly.



Device depiction







No.	Designation
1	Transport handle
2	Control panel
3	Air outlet
4	Colour LED for current room humidity
5	Condensation tank
6	Air inlet with air filter
7	Condensation drain hose connection
8	Power cable holder
9	Air filter
10	Condensation drain hose

Transport and storage

Note

If you store or transport the device improperly, the device may be damaged.

Note the information regarding transport and storage of the device.

Transport

Please note that additional transport regulations might apply to devices containing flammable refrigerants. The equipment's arrangement and the maximum number of components to be transported together can be gathered from the applicable transport regulations.

To make the device easier to transport, it is fitted with a carry handle.

Before transporting the device, observe the following:

- Switch the device off.
- Hold onto the mains plug while pulling the power cable out of the mains socket.
- Drain the remaining condensate from the device and the condensation drain hose (see chapter Maintenance).
- Do not use the power cable to drag the device.

After transporting the device, proceed as follows:

Set up the device in an upright position after transport.

Storage

Before storing the device, proceed as follows:

- Drain the remaining condensate from the device and the condensation drain hose (see chapter Maintenance).
- Hold onto the mains plug while pulling the power cable out of the mains socket.

When the device is not being used, observe the following storage conditions:

- Only store the device in a room measuring more than 4 m².
- Only position the device in rooms where there is no source of ignition (e.g. open flames, an active gas appliance or an electric heater).
- Store the device in a dry location and protected from frost and heat.
- Store the appliance in an upright position where it is protected from dust and direct sunlight.
- If required, use a cover to protect the device from invasive dust.
- Place no further devices or objects on top of the device to prevent it from being damaged.



Assembly and start-up

Scope of delivery


- 1 x Device
- 1 x Condensation drain hose, length: 0.6 m, diameter:
 10 mm
- 1 x Air filter
- 1 x cable holder (pre-installed)
- 1 x Manual

Unpacking the device

- 1. Open the cardboard box and take the device out.
- 2. Completely remove the packaging.
- 3. Fully unwind the power cable. Make sure that the power cable is not damaged and that you do not damage it during unwinding.

Start-up

When positioning the device, observe the minimum distance from walls or other objects as described in the chapter Technical annex.



- Before restarting the device, check the condition of the power cable. If there are doubts as to the sound condition, contact the customer service.
- Only position the device in rooms where potentially leaking refrigerant cannot accumulate.
- Only position the device in rooms where there is no source of ignition (e.g. open flames, an active gas appliance or an electric heater).

- Only put up the device in an upright, stable position on firm ground.
- Do not create tripping hazards when laying the power cable or other electric cables, especially when positioning the device in the middle of the room. Use cable bridges.
- Make sure that extension cables are completely unrolled.
- When positioning the device, keep a sufficient distance to heat sources.
- Make sure that no curtains or other objects interfere with the air flow.
- When positioning the device, particularly in wet areas, secure it locally with an RCD (residual current device) which complies with the respective regulations.


Inserting the air filter

Note

Do not operate the device without an air filter inserted into the air inlet!

Without the air filter, the inside of the device will be heavily contaminated. This could reduce the performance and result in damage to the device.


 Make sure that the air filter is installed before switching the device on.





Inserting the condensation tank

- Ensure that the float inside the condensation tank is inserted correctly.
- Ensure that the condensation tank is empty and inserted correctly.




Connecting the power cable

Insert the mains plug into a properly secured mains socket.

Operation

- Avoid open doors and windows.
- After being switched on, the device operates fully automatically.
- The fan continues to run in dehumidification mode even after the selected setpoint has been reached.



Operating elements

No.	Designation	Meaning
11	Timer LED	Illuminated when the timer is activated.
12	Drying LED	Illuminated when the self- cleaning function is activated
13	Low LED	Is illuminated at low fan speed
14	High LED	Is illuminated at high fan speed (function for drying laundry)
15	Condensation tank full LED	Is illuminated if the condensation tank is full or not installed correctly
16	Continuous LED	Is illuminated if the continuous operation mode is selected
17	Auto LED	Is illuminated if the automatic operation mode is selected
18	On/Off LED	Is illuminated if the device is in standby mode and switched on
19	On/Off button	Switching the device on or off
20	<i>Mode</i> button	Changing the operating mode
21	Humidity button	For setting the desired relative humidity level



No.	Designation	Meaning
22	Segment display	Indicates the relative humidity level, the current humidity level and the number of hours of the timer
23	Speed button	For setting the desired fan speed (function for drying laundry)
24	Self-cleaning function button	Switching the self-cleaning function on or off
25	<i>Timer</i> button	For switching the timer function on and off: 1 h to 24 h

Colour LED for current room humidity

Regardless of the operating mode, the colour LED (4) indicates the current relative room humidity by means of 3 different colours.

If you press the *Mode* button (20) and the *Humidity* button (21) simultaneously, you can switch off the colour LED (4).

LED colour	Meaning						
Blue	Relative room humidity below 40 %						
Green	Optimal relative room humidity between 40 % and 60 %						
Red	Illuminated: relative room humidity is equal to/ or above 60 %; Flashing: water tank is full (accompanied by an acoustic signal)						

Switching the device on

Once you have completely installed the device as described in the chapter Assembly and start-up, you can switch it on.

- 1. Press the *Power* button (19).
 - \Rightarrow The On/off LED (18) is illuminated.
 - ⇒ The *Auto* LED (17) and the *Low* LED (13) are illuminated when you switch on the device for the first time.

Operating modes

- Automatic operation
- Continuous operation

Setting the operating mode

- 1. Repeatedly press the *Mode* button (20) to change the operating mode.
 - ⇒ In continuous operation mode, the *Continuous* LED (16) is illuminated.
 - ⇒ In automatic operation mode, the *Auto* LED (17) is illuminated.

Automatic operation

The device dehumidifies the air continuously until the set relative humidity level is reached.

Please proceed as follows to adjust the desired humidity value:

- 1. Repeatedly press the *Humidity* button (21).
 - ⇒ The selected humidity value is indicated on the segment display (22).
 - ⇒ The colour LED (4) is illuminated depending on the room humidity level.

This operating mode can also be used for drying laundry. To do so, select the highest fan speed and observe the recommended humidity values listed under laundry drying.

Continuous operation

Regardless of the humidity level, the device dehumidifies continuously.

In continuous operation, only the fan speed can be manually selected.

The current humidity level is indicated on the segment display (22) and the colour LED (4) is illuminated depending on the room humidity level.



Info

For continuous operation a condensation drain hose can be connected in order to continuously drain the accumulating condensate.

Setting the fan speed

You can change between low and high fan speed.

- 1. Press the Fan speed button (23).
 - ⇒ If the fan speed is set to a low level, the *Low* LED (13) is illuminated.
 - ⇒ If the fan speed is set to a high level, the *High* LED (14, laundry drying function) is illuminated.

Auto stop function

Once the condensation tank is full, the device will stop automatically. The *Condensation tank full* LED (15) is illuminated. Empty the condensation tank as described in section *Emptying the condensation tank*.



Memory function

If you switch the device back on again, the settings selected for the operating mode, the relative humidity level and fan speed are saved. If a timer has been set, it will not be saved.

The device memorises the settings even during short power failures. In this case, the device automatically switches back on. The previous settings are saved except for the timer.

Self-cleaning function / Internal drying

This function serves to dry the interior of the device in order to prevent the formation of mould or similar inside the device due to residual moisture. The self-cleaning function should be used if the device is not operated or is stored for a longer period of time. Self-cleaning takes approx. 50 minutes. First, the inside of the device is dried at a high fan speed for approx. 30 minutes. Afterwards, the fan runs at low speed for about 20 minutes. Once the self-cleaning process is complete, the device switches to standby mode.

- 1. Press the Self-cleaning function button (24).
 - ⇒ The *Drying* LED (12) is illuminated.
 - \Rightarrow The fan runs at the highest speed.
- 2. Press the *Self-cleaning function* button (24) to switch off the self-cleaning function again.
 - ⇒ The device will switch to standby mode.

Setting the timer

Note

The device must not be left unattended in a freely accessible room with an activated timer.

The timer has two modes of operation:

- Automatic switch-on upon expiry of a preset number of hours
- Automatic switch-off upon expiry of a preset number of hours

The function can be set in addition in all operating modes. The number of hours can be set in hourly increments (1 h to max. 24 h).

Automatic switch-on

- ✓ The device is in standby mode.
- Repeatedly press the Timer button (25) until the desired number of hours until automatic switch-on is indicated on the segment display (22).
 - ⇒ The set number of hours appears on the segment display (22).
 - ⇒ The device switches on after the predefined time.

Notes regarding automatic switch-on:

- Manually switching the device on disables the automatic switch-on function.
- If you select 0 hours, the timer will be off.

Automatic switch-off

- ✓ The device is switched on.
- 1. Repeatedly press the *Timer* button (25) until the desired number of hours until automatic switch-off is indicated on the segment display (22).
 - ⇒ The set number of hours appears on the segment display (22).
 - ⇒ The device switches off after the predefined time.


Notes regarding automatic switch-off:

- Manually switching the device off disables the automatic switch-off function.
- If you select 0 hours, the timer will be off.

Operation with hose attached to the condensation connection


For continuous operation or unattended dehumidification, please connect the supplied condensation drain hose to the device.

- ✓ The supplied hose (diameter = 10 mm) is ready for use.
- ✓ The device is switched off.
- 1. Remove the sealing cap.
- 2. Push one end of the hose onto the hose connection.





Guide the other hose end to a suitable drain or sufficiently dimensioned collection container. Please note that the hose must not be kinked.



4. Remove the hose if you want to collect the condensate in the condensation tank again. Allow the hose to dry prior to storage.

Automatic defrost

At low ambient temperatures, ice may form at the evaporator during dehumidification. The device will then carry out an automatic defrost. Dehumidification is briefly interrupted during defrosting. The fan keeps running. The duration of the defrost process can vary. Do not switch off the device during automatic defrost. Do not remove the mains plug from the mains socket.

Drying laundry

In addition, the device may also be used as a kind of clothes dryer to dry wet laundry in living or working spaces.

When positioning the device or a clothes horse, please observe the minimum distances specified in the technical data.

The following humidity values are suitable for drying laundry:

- cupboard dry = 46 % relative humidity
- iron dry = 58 % relative humidity
- slightly dried = 65 % relative humidity

Adjust the settings for the relative humidity level to the device (e.g. 60 % relative humidity for iron dry laundry). If necessary, use a measuring device to determine the humidity level.

Shutdown



Warning of electrical voltage

Do not touch the mains plug with wet or damp hands.

- If you would like to take the device out of operation for a longer period of time, use the self-cleaning function to dry the inside of the device.
- Press the On/off button (19) to switch the device off.
- Hold onto the mains plug while pulling the power cable out of the mains socket.
- If necessary, remove the condensation drain hose and any residual fluid from it.
- Empty the condensation tank, if need be.
- Clean the device according to the Maintenance chapter.
- Store the device according to the Transport and storage chapter.

Errors and faults

The device has been checked for proper functioning several times during production. If malfunctions occur nonetheless, check the device according to the following list.

Note

Wait for at least 3 minutes after maintenance and repair work. Only then switch the device back on.

The device does not start:

- Check the power connection.
- Check the power cable and mains plug for damage.
- Check the on-site fusing.
- Check the condensation tank for correct seating.
- Check the room temperature. Observe the device's permissible operating range according to the technical data.

The device is running, but there is no formation of condensate:

- Check the float in the condensation tank for dirt. If necessary, clean the condensation tank. The float must be able to move freely.
- Check the room temperature. Observe the device's permissible operating range according to the technical data.
- Ensure that the relative room humidity complies with the technical data.
- Check the air filter for dirt. If necessary, clean or replace the air filter.
- From the outside, check the condenser for dirt (see chapter Maintenance). If the condenser is dirty, have it cleaned by a specialist company or by Trotec.
- The device might carry out an automatic defrost. During automatic defrost, the device does not dehumidify.



The device is loud or vibrates:

 Check whether the device is set up in a stable and upright position.

Condensate is leaking:

Check the device for leaks.

The compressor does not start:

- Check the room temperature. Observe the device's permissible operating range according to the technical data.
- Ensure that the relative room humidity complies with the technical data.
- Check whether the overheating protection of the compressor has tripped. Disconnect the device from the mains and let it cool down for approx. 10 minutes before reconnecting it.
- The device might carry out an automatic defrost. During automatic defrosting, the error code P1 appears on the display. No dehumidification is carried out during this time.

The device gets very warm, is loud or is losing performance:

- Check the air inlets and air filters for dirt. Remove external dirt.
- From the outside, check the device for dirt (see chapter Maintenance). If the inside of the device is dirty, have it cleaned by a specialist company for cooling and airconditioning or by Trotec.

The device still does not operate correctly after these checks:

Please contact the customer service. If necessary, bring the device to a specialist company for cooling and air-conditioning or to Trotec for repair.

Available accessories



Warning

Only use accessories and additional equipment specified in the instructions.

Using insertion tools or accessories other than those specified in the instructions may cause a risk of injury.

Designation	Article number					
Activated carbon filter	7.710.000.869					



Maintenance

Maintenance intervals

Maintenance and care interval	before every start-up	as needed	at least every 2 weeks	at least every 4 weeks	at least every 6 months	at least annually
Check air inlet and outlet for dirt and foreign objects and clean if necessary	Х			Х		
Clean the exterior		Х				Х
Visually check the inside of the device for dirt		Х				Х
Check the air filter for dirt and foreign objects and clean or replace if necessary	Х		Х			
Replace the air filter					Х	
Check for damage	Х					
Check the attachment screws		Х				Х
Test run						Х
Empty and clean the condensation tank and/or drain hose		Х				

Maintenance and care log

Device type:	Device number:
/UVIUU LYDU	

Maintenance and care interval	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Check air inlets and outlets for dirt and foreign objects and clean if necessary																
Check the air filter for dirt and foreign objects and clean or replace if necessary																
Clean the exterior																
Visually check the inside of the device for dirt																
Replace the air filter																
Check the attachment screws																
Test run																
Empty and clean the condensation tank and/or drain hose																
Comments																

1. Date:	2. Date:	3. Date:	4. Date:
			Signature:
5. Date:	6. Date:	7. Date:	8. Date:
Signature:	1		
9. Date:	10. Date:	11. Date:	12. Date:
Signature:			
13. Date:	14. Date:	15. Date:	16. Date:
Signature:	Signature:	Signature:	Signature:



Activities required before starting maintenance



Warning of electrical voltage

Do not touch the mains plug with wet or damp hands.

- Switch the device off.
- Hold onto the mains plug while pulling the power cable out of the mains socket.



Warning of electrical voltage

Tasks which require the device to be opened must only be carried out by authorised specialist companies or by Trotec.

Refrigerant circuit



Dangei

Natural refrigerant propane (R290)!

H220 – Extremely flammable gas.

H280 – Contains gas under pressure; may explode if heated.

P210 – Keep away from heat, sparks, open flames and other ignition sources. No smoking.

P377 – Leaking gas fire: Do not extinguish, unless leak can be stopped safely.

P410+P403 – Protect from sunlight. Store in a well-ventilated place.

 The entire refrigerant circuit is a maintenance-free, hermetically sealed system and may only be maintained or repaired by specialist companies for cooling and airconditioning or by Trotec.

Safety signs and labels on the device

Check the safety signs and labels attached to the device at regular intervals. Replace illegible safety signs!


Cleaning the housing

Clean the housing with a soft, damp and lint-free cloth. Make sure that no moisture enters the housing. Protect electrical components from moisture. Do not use any aggressive cleaning agents such as cleaning sprays, solvents, alcohol-based or abrasive cleaners to dampen the cloth.

Visual inspection of the inside of the device for dirt

- 1. Remove the air filter.
- 2. Use a torch to illuminate the openings of the device.
- 3. Check the inside of the device for dirt.
- 4. If you see a thick layer of dust, have the inside of the device cleaned by a specialist company for cooling and airconditioning or by Trotec.

5. Put the air filter back in.




Cleaning the air filter

Note

Ensure that the air filters are neither worn nor damaged. The corners and edges of the air filters must not be deformed or rounded. Before reinserting the air filters, make sure that they are undamaged and dry!


The air filters have to be cleaned as soon as they are dirty. This is brought to light e.g. by a reduced capacity (see chapter Errors and faults).

1. Remove the air filter from the device.






2. Clean the filter using a slightly damp, soft, lint-free cloth. If the filter is heavily contaminated, clean it with warm water mixed with a neutral cleaning agent.




- 3. Allow the filter to dry completely. Do not insert a wet filter into the device!
- 4. Reinsert the air filter into the device.




Emptying the condensation tank

If the condensation tank is full, the *Condensation tank full* LED (15) will be illuminated. The compressor and fan will switch off.

1. Take the condensation tank out of the device.



2. Empty the condensation tank over a drain or sink.



3. Rinse the tank with clear water. Clean the tank regularly using a mild cleaning agent (no detergent!).




4. Refit the condensation tank into the device.

Make sure not to damage the float when inserting or removing the condensation tank.

In doing so, make sure that the float is positioned correctly.

In doing so, make sure that the condensation tank is inserted correctly, for otherwise the device cannot be switched back on.



Activities required after maintenance

If you want to continue using the device:

• Reconnect the device to the mains.

If you do not intend to use the device for a considerable time:

• Store the device according to the Transport and storage chapter.


Technical annex

Technical data

Parameter	Value
Model	TTK 33 E
Max. dehumidification performance	14 I / 24 h
Dehumidification performance @ 30 °C and 80 % RH	12 I / 24 h
Air flow rate	80 m ³ /h
Operating range (temperature)	5 °C to 32 °C
Operating range (relative humidity)	30 % to 80 % RH
Pressure suction side	0.8 MPa
Pressure outlet side	2.8 MPa
Max. permissible pressure	3.8 MPa
Mains supply	220-240 V / 50 Hz
Max. power consumption	240 W
Nominal current	1.3 A
Type of protection	IPX1
Fusing —	T 3.15 A / 250 V AC
Refrigerant	R290
Amount of refrigerant	52 g
GWP factor	3
CO ₂ equivalent	0.000156 t
Water tank	1.5 l
Sound pressure level	43 dB (A)
Dimensions (length x width x height)	205 x 270 x 420 mm
Minimum distance to walls and other objects	
-	50 cm
B: rear	
C: side D: front	
Weight	10 kg
vveigiit	I U NY



Circuit diagram






Overview of spare parts



Info

The position numbers of the spare parts differ from those describing the positions of the components mentioned in these instructions.





List of spare parts

No.	Spare part	No.	Spare part	No.	Spare part
1	back panel	12	condensor	27	float
2	winding holder	13	filter	28	water tank
3	rubber plug	17	air duct	29	compressor
4	activated carbon filter	18	shaded pole motor	30	base panel
5	filter	19	fan wheel	31	foot pad
6	handle	20	electric control box metal	32	tube
7	temperature and humidity sensor	21	electric control box plastic	33	frame holder
8	mask	23	side panel	34	support plate
9	top panel	24	PCB	35	sensory switch
10	display	25	electric control box matel		
11	evaporator	26	front panel		

Disposal

Always dispose of packing materials in an environmentally friendly manner and in accordance with the applicable local disposal regulations.

The icon with the crossed-out waste bin on waste electrical or electronic equipment is taken from Directive 2012/19/EU. It states that this device must not be disposed of with the household waste at the end of its life. You will find collection points for free return of waste electrical and electronic equipment in your vicinity. The addresses can be obtained from your municipality or local administration. You can also find out about other return options that apply for many EU countries on the website https://hub.trotec.com/?id=45090. Otherwise, please contact an official recycling centre for electronic and electrical equipment authorised for your country.

The separate collection of waste electrical and electronic equipment aims to enable the re-use, recycling and other forms of recovery of waste equipment as well as to prevent negative effects for the environment and human health caused by the disposal of hazardous substances potentially contained in the equipment.

Have the refrigerant (propane) disposed of appropriately and according to the national regulations by a company with the relevant certification (European Waste Catalogue 160504).

Only for United Kingdom

According to Waste Electrical and Electronic Equipment Regulations 2013 (SI 2013/3113) (as amended) devices that are no longer usable must be collected separately and disposed of in an environmentally friendly manner.

Trotec GmbH

Grebbener Str. 7
D-52525 Heinsberg
1+49 2452 962-400
4+49 2452 962-200

info@trotec.com www.trotec.com